

## VALVE GUIDE

Item Code	Item Description	Engine Name	Model Name	Bore Dia	OEM No	O.E. NUMBER
V051A04010200N	VALVE GUIDE (INLET & EXHAUST) ANDORIA S-231 (IN. & EX. BOTH ARE SAME.)	ANDORIA	S-231	102.00		
V051A04020200N	VALVE GUIDE (INLET & EXHAUST) ANDORIA S-320 (18 H.P.) IN. & EX. BOTH ARE SAME.	ANDORIA	S-320 (18 H.P.)	120.00	OEM # 150761	
V051A07010200N	VALVE GUIDE (INLET & EXHAUST) ARMSTRONG SIDDELEY 14/22 H.P.	ARMSTRONG SIDDELEY	14/22 H.P.	107.95		
V051A08010200N	VALVE GUIDE (INLET & EXHAUST) ASAA F-140 (IN. & EX. BOTH ARE SAME.)	ASAA	F-140	140.00		
V051B08140200N	VALVE GUIDE (INLET & EXHAUST) B.M.C 98 (4,6 CYL.)	B.M.C	98	98.00	OEM # (IN.) 86K144 & (EX.) 86K145	AE # (IN.) VAG444, (EX.) VAG414 & METELLI # (IN.) 01-0358, (EX.) 01-0359
BAJAJ0103	VALVE GUIDE (INLET & EXHAUST) BAJAJ 3 WHEELER (RE) 3 PORT	BAJAJ	3 WHEELER (RE) 3 PORT	57.00		
BAJAJ0104	VALVE GUIDE (INLET & EXHAUST) BAJAJ 3 WHEELER (RE) 5 PORT	BAJAJ	3 WHEELER (RE) 5 PORT	57.00		
BAJAJ0100	VALVE GUIDE (INLET & EXHAUST) BAJAJ DISCOVER 100 ST (4 VALVES)	BAJAJ	DISCOVER 100 ST (4 VALVES)	47.00		
BAJAJ0101	VALVE GUIDE (INLET & EXHAUST) BAJAJ DISCOVER 125 ST (4 VALVES)	BAJAJ	DISCOVER 125 ST (4 VALVES)	54.00		
BAJAJ0096	VALVE GUIDE (INLET & EXHAUST) BAJAJ DISCOVER Dtsi 125cc	BAJAJ	DISCOVER Dtsi 125cc	57.00		
BAJAJ0097	VALVE GUIDE (INLET & EXHAUST) BAJAJ PULSAR 135cc	BAJAJ	PULSAR 135cc	54.00		
BAJAJ0098	VALVE GUIDE (INLET & EXHAUST) BAJAJ PULSAR 180 Dtsi	BAJAJ	PULSAR 180 Dtsi	63.50		
BAJAJ0102	VALVE GUIDE (INLET & EXHAUST) BAJAJ PULSAR 200 NS (4 VALVES)	BAJAJ	PULSAR 200 NS (4 VALVES)	72.00		
BAJAJ0099	VALVE GUIDE (INLET & EXHAUST) BAJAJ PULSAR 200cc,220cc	BAJAJ	PULSAR 200cc,220cc	67.00		
V051B04010200N	VALVE GUIDE (INLET & EXHAUST) BEDFORD J4/J6 (220/330)	BEDFORD	J4/J6 (220/330)	103.175	OEM #=(IN.) 7134379 & (EX.) 7166435	TRW #=(IN.) 110-G00474 & (EX.) 110-G50828
V051B07040200N	VALVE GUIDE (INLET & EXHAUST) BLACKSTONE JP (16 H.P.)	BLACKSTONE	JP (16 H.P.)	149.22	OEM # (IN.) X3411580 & (EX.) X3411330	
V051B07070200N	VALVE GUIDE (INLET & EXHAUST) BLACKSTONE OP (26 H.P.)	BLACKSTONE	OP (26 H.P.)	184.15	OEM # (IN.) X6811060 & (EX.) X3611520	

V051B15050200N	VALVE GUIDE (INLET & EXHAUST) BUKH G-105/GH-105/EH-105/EV-105 (IN. & EX. BOTH ARE SAME.)	BUKH	G-105	105.00		
V051B15070200N	VALVE GUIDE (INLET & EXHAUST) BUKH GH-130 (IN. & EX. BOTH ARE SAME.)	BUKH	GH-130	130.00		
V051C03060203N	VALVE GUIDE (INLET & EXHAUST) CATERPILLAR D330C/3304,D333C/3306,1673C (D- 4D) IN. & EX. BOTH ARE SAME.	CATERPILLAR	D330C/330 4,D333C/33 06	120.65	OEM # 2P1262	METELLI # 01-1239 & SBI # 140-7194
V051C11050200N	VALVE GUIDE (INLET & EXHAUST) COMET 10 H.P. (IN. & EX. BOTH ARE SAME.)	COMET	10 H.P.		OEM # 12134	PART # 12134
V051C11080200N	VALVE GUIDE (INLET & EXHAUST) COMET 5/6.5/8 HP (IN. & EX. BOTH ARE SAME.)	COMET	5/6.5/8 H.P. (A/C & W/C)		OEM # 12.133	PART # 12133
V051C15110200N	VALVE GUIDE (INLET & EXHAUST) CUMMINS 855,NH250,NT400 (IN. & EX. BOTH ARE SAME.)	CUMMINS	855,NH250, NT400	139.70	OEM # 3006456 & 3050369	SBI # 140-7994
V051D06050200N	VALVE GUIDE (INLET & EXHAUST) DAIHATSU S-70 (850 CC) IN. & EX. BOTH ARE SAME. (W/O WIRE CLIP)	DAIHATSU	S-70 (850 CC)		OEM # (IN. & EX.) 1112487701	
V071D06050200N	VALVE GUIDE WITH WIRE CLIP (INLET & EXHAUST) DAIHATSU S-70 (850 CC) IN. & EX. BOTH ARE SAME.	DAIHATSU	S-70 (850 CC)		OEM # (IN. & EX.) 1112487701	
V054D13100200N	VALVE GUIDE (INLET & EXHAUST) DEUTZ FL-514,FL-614 (Ø10.00) STD (IN. & EX. BOTH ARE SAME.)	DEUTZ	FL-514,FL- 614	110.00	OEM # G7028	
V051D13110200N	VALVE GUIDE (INLET & EXHAUST) DEUTZ FL-514,FL-614 (Ø12.00) STD (IN. & EX. BOTH ARE SAME.)	DEUTZ	FL-514,FL- 614	110.00	OEM # G7025	
V051D13220200N	VALVE GUIDE (INLET & EXHAUST) DEUTZ MAH-716/HD-10 (IN. & EX. BOTH ARE SAME.)	DEUTZ	MAH- 716/HD-10	120.00		
V071D13130200N	VALVE GUIDE WITH WIRE CLIP (INLET & EXHAUST) DEUTZ FL-511,FL-912 (STD) IN. & EX. BOTH ARE SAME.	DEUTZ	FL-511,FL- 912	100.00	OEM # (GUIDE) 02232528, 2232528EZ (STD) & (WIRE CLIP) 1215500, 1215500EF	BF # 20080591284, FRECCIA # G2818, METELLI # 011518 & TRW # 812246
V071D13130200Y	VALVE GUIDE WITH WIRE CLIP (INLET & EXHAUST) KHD/ DEUTZ FL-912 (IN. & EX. BOTH ARE SAME) BP-SRB BP-SRB (MODIFIED)	DEUTZ	FL-912	100.00	OEM # 02232528 & 2232528EZ (STD)	BF # 20080591284, FRECCIA # G2818, METELLI # 011518 & TRW # 812246
V051D15200200N	VALVE GUIDE (INLET & EXHAUST) DONGFENG DF-195/S-195 (IN. & EX. BOTH ARE SAME.)	DONGFENG	DF-195/S- 195	95.00		
V051D15090200N	VALVE GUIDE (INLET & EXHAUST) DONGFENG R-175/DF-175 (IN. & EX. BOTH ARE SAME.)	DONGFENG	R-175			
V051D15120200N	VALVE GUIDE (INLET & EXHAUST) DONGFENG R-185,EM-185 (IN. & EX. BOTH ARE SAME.)	DONGFENG	R-185,EM- 185	85.00		
V051D15160200N	VALVE GUIDE (INLET & EXHAUST) DONGFENG S-1110 (IN. & EX. BOTH ARE SAME.)	DONGFENG	S-1110	110.00		

# AECO ENGINEERING CO.



V051D15190200N	VALVE GUIDE (INLET & EXHAUST) DONGFENG ZH-1115 WA/S-1115 (IN. & EX. BOTH ARE SAME.)	DONGFENG	ZH-1115 WA			
V051E02010200N	VALVE GUIDE (INLET & EXHAUST) EKM IH-65 (IN. & EX. BOTH ARE SAME.)	EKM	IH-65			
V051F04100200N	VALVE GUIDE (INLET & EXHAUST) FIAT IVECO 40.10,40.12 (IN. & EX. BOTH ARE SAME.)	FIAT IVECO	40.10,40.12	93.00,94.40	OEM # 4749399	METELLI # 01-1815
V051F03150200N	VALVE GUIDE (INLET & EXHAUST) FIAT IVECO 8040.02,8060.25,8065.04,ZASTAUA 624 (IN. & EX. BOTH ARE SAME.)	FIAT IVECO	8040.02,806 0.25,8065.0 4,ZASTAUA 624	103.00	OEM # 4648421 & 4802126	KS # 50004353
V051F04200200N	VALVE GUIDE (INLET & EXHAUST) FIAT IVECO 8215.01,8215.02	FIAT IVECO	8215.01,821 5.02		OEM # (IN.) 4630627 & (EX.) 4647763	(IN.) METELLI # 01- 0278, FRECCIA # G2337 & (EX.) METELLI # 01-0273, FRECCIA # G2340
V051F04200332N	VALVE GUIDE (INLET & EXHAUST) FIAT IVECO 8215.01,8215.02 (1 SET OF 12 NOS.)	FIAT IVECO	8215.01,821 5.02		OEM # (IN.) 4630627 & (EX.) 4647763	(IN.) METELLI # 01- 0278, FRECCIA # G2337 & (EX.) METELLI # 01-0273, FRECCIA # G2340
V051F04070200N	VALVE GUIDE (INLET & EXHAUST) FIAT IVECO CO3,CP3	FIAT IVECO	CO3,CP3	110.00	OEM # (IN.) 8822383, 4758794 & (EX.) 8823263, 4758798	BIEFFE # (IN.) G25- 547A & (EX.) G25- 548A
PIAGGIO0005	VALVE GUIDE (INLET & EXHAUST) GREAVES PIAGGIO APE	GREAVES PIAGGIO	APE	86.00		
HONDA0005	VALVE GUIDE (INLET & EXHAUST) HERO HONDA CBZ	HONDA	CBZ	63.50		
V051H09140233N	VALVE GUIDE (INLET & EXHAUST) HONDA D16A, D18A, D16A6 & D16Y1 (ACCORD 16V) INLET WITH WIRE CLIP & EXHAUST WITH POCKET & W/O WIRE CLIP (AB) 1 SET OF 16 NOS.	HONDA	D16A, D18A, D16A6 & D16Y1		OEM # (IN.) 12204PJ7305 & (EX.) 12205PJ7305	
V051H09170212N	VALVE GUIDE (INLET & EXHAUST) HONDA EF, EG, EN, EJ, EB1, EB2 & EB3 (CIVIC 78-83) AB	HONDA	EF, EG, EN, EJ, EB1, EB2 & EB3 (CIVIC 78- 83)		OEM # (IN.) 12204634920, 12208634000 & (EX.) 12205657305, 12209634000, 12209634670	SBI # (IN.) 140-7530 & (EX.) 140-7531
V071H09040200N	VALVE GUIDE WITH WIRE CLIP (INLET & EXHAUST) HONDA ACCORD EP/EK	HONDA	ACCORD EP/EK		OEM # (IN.) 12204689300, 12204689305 & (EX.) 12205689300, 12205689305	METELLI # (IN.) 01- 1882 & (EX.) 01- 1883

V051H10150332N	VALVE GUIDE (INLET & EXHAUST) HYUNDAI 8V-91A (1 SET OF 12 NOS.)	HYUNDAI	8V-91A		OEM # (IN.) 925211239 & (EX.) 925211238	
V051H10140210N	VALVE GUIDE (INLET & EXHAUST) HYUNDAI ATOS (1 SET OF 8 NOS.)	HYUNDAI	ATOS			GIEFFE # G52166 / G52167
V051H10120200N	VALVE GUIDE (INLET & EXHAUST) HYUNDAI H-100	HYUNDAI	H-100			
V051i03240200N	VALVE GUIDE (INLET & EXHAUST) INTERNATIONAL DT-360,DT-466 (IN. & EX. BOTH ARE SAME.)	INTERNATI ONAL (IHC)	DT-360,DT- 466	109.22	OEM # 675439C1	SBI # 140-7431 & S.P. # VG695
V051i05090310N	VALVE GUIDE (INLET & EXHAUST) ISUZU 4BA1,4BB1,4BC1,4BC2 (1 SET OF 8 NOS.) IN. & EX. BOTH ARE SAME.	ISUZU	4BA1,4BB1, 4BC1,4BC2	98.00,102.00	OEM # 5117210010	SBI # 140-8023, METELLI # 01-2150 & GIEFFE # G52150
V051i05330310N	VALVE GUIDE (INLET & EXHAUST) ISUZU 4HF1 (IN. & EX. BOTH ARE SAME.) 1 SET OF 8 NOS.	ISUZU	4HF1	112.00		
V071J04030200N	VALVE GUIDE WITH WIRE CLIP (INLET & EXHAUST) JENBACH JW-15 (IN. & EX. BOTH ARE SAME.)	JENBACH	JW-15	115.00	OEM # C0721	
V071J04040200N	VALVE GUIDE WITH WIRE CLIP (INLET & EXHAUST) JENBACH JW-20 (IN. & EX. BOTH ARE SAME.)	JENBACH	JW-20	125.00		
V051J05020200N	VALVE GUIDE (INLET & EXHAUST) JIANG DONG ZH-1115 (IN. & EX. BOTH ARE SAME.)	JIANG DONG	ZH-1115	115.00		
V051K01010200N	VALVE GUIDE (INLET & EXHAUST) KAMAZ TRUCK (IN. & EX. BOTH ARE SAME.)	KAMAZ				
V051K07020200N	VALVE GUIDE (INLET & EXHAUST) KIRLOSKAR AV/JV/TV; PETTER AV/PH (IN. & EX. BOTH ARE SAME.)	KIRLOSKAR /PETTER	AV/JV/TV; AV/PH	80.00/85.00/ 87.31/87.50	OEM # (IN. & EX.) JB40	
V051K13140200N	VALVE GUIDE (INLET & EXHAUST) KUBOTA ER-50/GA-80 (IN. & EX. BOTH ARE SAME.)	KUBOTA	ER-50			
V051K13170207N	VALVE GUIDE (INLET & EXHAUST) KUBOTA ER-65,GA-90/100,KND-70 (IN. & EX. BOTH ARE SAME.) KSKCL	KUBOTA	ER-65,GA- 90/100,KN D-70			
V051K13220200N	VALVE GUIDE (INLET & EXHAUST) KUBOTA ET-70/KND-70A/75,ET-80 (IN. & EX. BOTH ARE SAME.)	KUBOTA	ET-70/KND- 70A/75,ET- 80			
V051K13250200N	VALVE GUIDE (INLET & EXHAUST) KUBOTA ET-95/110 (IN. & EX. BOTH ARE SAME.) KSKCL	KUBOTA	ET-95			
V051K13640200N	VALVE GUIDE (INLET & EXHAUST) KUBOTA KND-1600 (MAD)	KUBOTA	KND-1600 (MAD)		OEM # (IN.) 141911354-0 & (EX.) 141911358-0	
V051K13370200N	VALVE GUIDE (INLET & EXHAUST) KUBOTA KND-3200	KUBOTA	KND-3200	150.00	OEM #=(IN.) 14195-13540 & (EX.) 14181- 13580	
V051K13530207N	VALVE GUIDE (INLET & EXHAUST) KUBOTA KND-5B (IN. & EX. BOTH ARE SAME.) KSKCL	KUBOTA	KND-5B			
V051L01000310N	VALVE GUIDE (INLET & EXHAUST) LADA (SET OF 8 NOS)	LADA				

V051L01040200N	VALVE GUIDE (INLET & EXHAUST) LADA 1200/1500 (GRADE-SL25) SRB (DWG. REF. NO. U710/U720)	LADA	1200/1500	76.00,78.99	OEM # (IN.) 21011007031 & (EX.) 21011007033	METELLI # (IN.) 01- 1369 & (EX.) 01- 1370
V071L01020210N	VALVE GUIDE WITH WIRE CLIP (INLET & EXHAUST) LADA 1200,1300,1500,1600 (1 SET OF 4 NOS. (IN.) + 4 NOS. (EX.) = 8 NOS.)	LADA	1200,1300,1 500,1600	76.00,78.99	OEM # (IN.) 21011007032 & (EX.) 21011007033	AE # (IN.) VAG92174 & (EX.) VAG92175, TRW # (IN.) 110-G01770 & (EX.) 110-G01771; KS # (IN.) 50004234
V051L07020200N	VALVE GUIDE (INLET & EXHAUST) LISTER 10/1 (10 H.P.)	LISTER	10/1 (10 H.P.)	120.00		
V051L07010206N	VALVE GUIDE (INLET & EXHAUST) LISTER 6/1 (6 H.P.) 8/1 (8 H.P.) BOTH GUIDE ARE INLET (W/O THREAD)	LISTER	6/1 (6 H.P.),8/1 (8 H.P.)	114.30	OEM # 01003039	
V051L07010205N	VALVE GUIDE (INLET & EXHAUST) LISTER 6/1 (6 H.P.) 8/1 (8 H.P.) ORIGINAL SIZE & EXH THREADED	LISTER	6/1 (6 H.P.),8/1 (8 H.P.)	114.30	OEM # (IN.) 01003039 & (EX.) 01003083	
V051L07010223N	VALVE GUIDE (INLET & EXHAUST) LISTER 6/1 (6 H.P.),8/1 (8 H.P.) INDIAN TYPE - GUPTA MAKE	LISTER	6/1 (6 H.P.),8/1 (8 H.P.)	114.30		
V051L07100200N	VALVE GUIDE (INLET & EXHAUST) LISTER HA HR	LISTER	HA,HR	101.60,108.00	OEM # (IN.) 35110400 & (EX.) 29150800	
V051L07140200N	VALVE GUIDE (INLET & EXHAUST) LISTER LD	LISTER	LD	76.20		
V051L07160200N	VALVE GUIDE (INLET & EXHAUST) LISTER LR	LISTER	LR	76.20	OEM # (IN.) 20110400 & (EX.) 20110321	
V051L07170200N	VALVE GUIDE (INLET & EXHAUST) LISTER LT	LISTER	LT	82.55	OEM # (IN.) 60130402 & (EX.) 60130321	
V051L07190200N	VALVE GUIDE (INLET & EXHAUST) LISTER SR WITH FLANGE (IN. & EX. BOTH ARE SAME.)	LISTER	SR	88.90		
V051L07200200N	VALVE GUIDE (INLET & EXHAUST) LISTER ST	LISTER	ST	95.25	OEM # (IN.) 20155640 & (EX.) 20155650	AE # (IN.) VAG92064 & (EX.) VAG92065
V051L07230200N	VALVE GUIDE (INLET & EXHAUST) LISTER TS,TL,TR	LISTER	TS,TL,TR	95.25,98.50	OEM # (IN.) 20130181 & (EX.) 20130170	
LML0005	VALVE GUIDE (INLET & EXHAUST) LML FREEDOM 110cc	LML	FREEDOM 110cc	53.00		
V071L08040400N	VALVE GUIDE WITH WIRE CLIP (INLET & EXHAUST) LOMBARDINI LDA 450 LDA 510 (IN. = C.I. & EX. = Br)	LOMBARDI NI	LDA 450,LDA 510	85.00	OEM # (IN.) 285484553 & (EX.) 285484550	METELLI # (IN.) 01- 0556 & (EX.) 01- 2211
MARUTI00470	VALVE GUIDE (INLET & EXHAUST) SUZUKI AX-100,MAX-100,SAMURAI	MARUTI/SU ZUKI	AX-100,MAX 100,SAMUR AI	50.00		

# AECO ENGINEERING CO.



V051P03010218N	VALVE GUIDE (INLET & EXHAUST) PERKINS 3.152/4.203/6.305 (NEW MODEL) BORE DIA.-7.96MM (IN. & EX. BOTH ARE SAME.)	MASSEY FERGUSON \ PERKINS	3.152/4.203 /6.305	91.49	OEM # 3316A031, 33261723, 4223519M1, 731126M1 & 732445M1	AE # VAG586, TRW # 110-G00586 & BEPCO # 30/41-3
V051P03010219N	VALVE GUIDE (INLET & EXHAUST) PERKINS 3.152/4.203/6.305 (NEW MODEL) SYR (BORE DIA.-7.94MM) IN. & EX. BOTH ARE SAME.	MASSEY FERGUSON \ PERKINS	3.152/4.203 /6.305	91.49	OEM # 3316A031, 33261723, 4223519M1, 731126M1 & 732445M1	AE # VAG586, TRW # 110-G00586 & BEPCO # 30/41-3
V051P03010208N	VALVE GUIDE (INLET & EXHAUST) PERKINS 3.152/4.203/6.305 (OLD MODEL) IN. & EX. BOTH ARE SAME.	MASSEY FERGUSON \ PERKINS	3.152/4.203 /6.305	91.49	OEM # 0420002	BEPCO # 41-11 & FRECCIA # G2533
V051P03090200N	VALVE GUIDE (INLET & EXHAUST) PERKINS P-4.212/4.236/4.248/6.354, PHASER 1000 SERIES T4.40/T6.60 (TURBO)	MASSEY FERGUSON \ PERKINS	P-4.212/4.236 /4.248/6.354, PHASER 1000 SERIES T4.40/T6.60 (TURBO)	98.476,100.00 ,101.054	OEM # (IN.) 33261731/32,3 343F001/02/31 /41,3637056M1 ,3640676M1,73 6297M1,422307 3M1 & (EX.) 33261751/52	TRW # (IN.) 110-G00601, (EX.) 110-G50933, AE # (IN.) VAG601, (EX.) 92300 (50933) & BEPCO # (IN.) 30/
V051M07010210N	VALVE GUIDE (INLET & EXHAUST) MASTER 2445 (1 SET OF 8 NOS.) IN. & EX. BOTH ARE SAME.	MASTER	2445			GIEFFE # G51355
V051M09260200N	VALVE GUIDE (INLET & EXHAUST) MAZDA SL,T3500	MAZDA	SL,T3500	100.00		
V051M12110200N	VALVE GUIDE (INLET & EXHAUST) MERCEDES OM 346,OM 355,OM 355A	MERCEDES	OM 346,OM 355,OM 355A	128.00	OEM # (IN.) 3460530929 & (EX.) 3550530330	(IN.) TRW # 81-1640, BF # 20080335550 & (EX.) TRW # 81-1641, AE # VAG92017, BF # 20080335551
V051M12140200N	VALVE GUIDE (INLET & EXHAUST) MERCEDES OM 352A	MERCEDES	OM 352A	97.00	OEM # (IN.) 31205302030 & (EX.) 321531230	(IN.) TRW # 81-1609, BF # 20080331458 & (EX.)
V051M15030200N	VALVE GUIDE (INLET & EXHAUST) MITSUBISHI 4D30,4D31	MITSUBISHI	4D30,4D31	100.00	OEM # (IN.) ME031886 & (EX.) ME031888	(IN.) METELLI # 01-2759 & (EX.) PART # VG-2602 & METELLI # 01-2760
V051M15110210N	VALVE GUIDE (INLET & EXHAUST) MITSUBISHI 4G51,4G54,4G63,4G64 (INLET W/O WIRE CLIP & EXHAUST WITH POCKET & WIRE CLIP) AB (1 SET OF 8 NOS.)	MITSUBISHI	4G51,4G54, 4G63,4G64	85.00,86.50,9 1.12	OEM # (IN.) MD020551, 04416 & (EX.) 2211532901, MD020561, 04418	METELLI # (IN.) 01-2168, (EX.) 01-2169 & SBI # (IN.) 140-7574 & (EX.) 140-7575
V051M15770200N	VALVE GUIDE (INLET & EXHAUST) MITSUBISHI 6G74	MITSUBISHI	6G74	96.00		SBI # (IN.) 140-8547 & (EX.) 140-8548
V051M15790200N	VALVE GUIDE (INLET & EXHAUST) MITSUBISHI G4EK/G4EKT	MITSUBISHI	G4EK/G4EKT		OEM # (IN.) 2211422905 & (EX.) 2211423901	SBI # (IN.) 140-8572 & (EX.) 140-8573
V051M15410200N	VALVE GUIDE (INLET & EXHAUST) MITSUBISHI HD-330	MITSUBISHI	HD-330	145.00	OEM # (IN.) EZ95079 & (EX.) EZ95078	

# AECO ENGINEERING CO.



V051M15420207N	VALVE GUIDE (INLET & EXHAUST) MITSUBISHI M11 (IN. & EX. BOTH ARE SAME.) KSKCL	mitsubishi	M11	92.00		
V051M15440207N	VALVE GUIDE (INLET & EXHAUST) MITSUBISHI M14/NM-155,M16/NM-180H (IN. & EX. BOTH ARE SAME.) KSKCL	mitsubishi	M14/NM-155,M16/NM-180H	96.00,100.00		
V051M15640207N	VALVE GUIDE (INLET & EXHAUST) MITSUBISHI SD-4,M5 (IN. & EX. BOTH ARE SAME.) KSKCL	mitsubishi	SD-4,M5	68.00		
V051M15650207N	VALVE GUIDE (INLET & EXHAUST) MITSUBISHI SD-5/NM-75,M7 (IN. & EX. BOTH ARE SAME.) KSKCL	mitsubishi	SD-5/NM-75,M7	78.00		
V071M15360207N	VALVE GUIDE WITH WIRE CLIP (INLET & EXHAUST) MITSUBISHI DI-700,DI-800 (IN. & EX. BOTH ARE SAME.) KSKCL	mitsubishi	DI-700,DI-800			
V071M15470207N	VALVE GUIDE WITH WIRE CLIP (INLET & EXHAUST) MITSUBISHI M85/NM-85,M95 (IN. & EX. BOTH ARE SAME.) KSKCL	mitsubishi	M85/NM-85,M95	80.00,85.00		
V051N03440200N	VALVE GUIDE (INLET & EXHAUST) NISSAN/DATSUN 1200/1500	NISSAN/DATSUN	1200/1500			
V051N03040200N	VALVE GUIDE (INLET & EXHAUST) NISSAN/DATSUN CA16,CA18,CA20	NISSAN/DATSUN	CA16,CA18,CA20	83.00,84.50	OEM # (IN.) 13212D0110, 13212D0111 & (EX.) 13213D0110	SBI # (IN.) 140-7826 & (EX.) 140-7827
V051N03430200N	VALVE GUIDE (INLET & EXHAUST) NISSAN/DATSUN E13,E15	NISSAN/DATSUN	E13,E15	76.00	OEM # (IN.) 1321201M01 & (EX.) 1321215M01, 1321301M01	TRW # (IN.) G-1107 & (EX.) G-1108
V051N03090200N	VALVE GUIDE (INLET & EXHAUST) NISSAN/DATSUN ED33 (IN. & EX. BOTH ARE SAME.)	NISSAN/DATSUN	ED33	100.00	OEM # 1321216500	
V051N03130212N	VALVE GUIDE (INLET & EXHAUST) NISSAN/DATSUN GA14DE,GA15DE,GA16DE (4 CYL.) AB	NISSAN/DATSUN	GA14DE,GA15DE,GA16DE	76.00	OEM # (IN.) 1321253Y60 & (EX.) 1321353Y60	SBI # (IN.) 140-8218 & (EX.) 140-8213
V051N03160200N	VALVE GUIDE (INLET & EXHAUST) NISSAN/DATSUN J13,J15	NISSAN/DATSUN	J13,J15	73.00,78.00	OEM # (IN.) 1321101W10, 1321130001 & (EX.) 1321301W00, 1321330001 & 1321330002	TRW # (IN.) G-1211, (EX.) G-1212 & SBI # (IN.) 140-7495, (EX.) 140-7498
V051N03210200N	VALVE GUIDE (INLET & EXHAUST) NISSAN/DATSUN ND6	NISSAN/DATSUN	ND6	110.00		
V051N03220200N	VALVE GUIDE (INLET & EXHAUST) NISSAN/DATSUN P,P40	NISSAN/DATSUN	P,P40	85.69		
V051N03230213N	VALVE GUIDE (INLET & EXHAUST) NISSAN/DATSUN P,P40 (NP)	NISSAN/DATSUN	P,P40	85.69	OEM # (IN.) & (EX.) 13213C6001	PART # (IN.) VG-780, (EX.) VG-781 & SBI # (IN.) , (EX.) 140-3089
V051N03180200N	VALVE GUIDE (INLET & EXHAUST) NISSAN/DATSUN P140	NISSAN/DATSUN	P140			

# AECO ENGINEERING CO.



V051N03240200N	VALVE GUIDE (INLET & EXHAUST) NISSAN/DATSUN PD6	NISSAN/DATSUN	PD6	125.00	OEM # (IN.) 1321196000 & (EX.) 1321396000	AE # (IN.) VAG92122 & (EX.) VAG92123
V051N03300200N	VALVE GUIDE (INLET & EXHAUST) NISSAN/DATSUN RD8	NISSAN/DATSUN	RD8	135.00		
V051N03340200N	VALVE GUIDE (INLET & EXHAUST) NISSAN/DATSUN SD22,SD23,SD25 (IN. & EX. BOTH ARE SAME.)	NISSAN/DATSUN	SD22,SD23, SD25	89.00	OEM # 13211V1700	SBI # 140-8209, METELLI # 01-2179 & GIEFFE # G-52179
V051N03350200N	VALVE GUIDE (INLET & EXHAUST) NISSAN/DATSUN SR20DE,SR20DET (4 CYL.)	NISSAN/DATSUN	SR20DE,SR2 0DET	86.00	OEM # (IN.) 1321253J60 & (EX.) 1321344F60	SBI # (IN.) 140-8216 & (EX.) 140-8217
V051N03360200N	VALVE GUIDE (INLET & EXHAUST) NISSAN/DATSUN TD27 (IN. & EX. BOTH ARE SAME.)	NISSAN/DATSUN	TD27	96.00	OEM # 1321243G01	TRW # G5115, METELLI # 01- 2561 & GIEFFE # G52561
V051N03370200N	VALVE GUIDE (INLET & EXHAUST) NISSAN/DATSUN TD42,TB42E/S (IN. & EX. BOTH ARE SAME.)	NISSAN/DATSUN	TD42,TB42 E/S	96.00		
V051N03380200N	VALVE GUIDE (INLET & EXHAUST) NISSAN/DATSUN VG30DE (6 CYL.)	NISSAN/DATSUN	VG30DE	87.10	OEM # (IN.) 13212F6560 & (EX.) 13213F6560	SBI # (IN.) 140-8543 & (EX.) 140-8544
V051N03390200N	VALVE GUIDE (INLET & EXHAUST) NISSAN/DATSUN VQ30DE (6 CYL.)	NISSAN/DATSUN	VQ30DE	93.00	OEM # (IN.) 1321258S60 & (EX.) 1321344F60	SBI # (IN.) 140-8190 & (EX.) 140-8217
V071N03190200N	VALVE GUIDE WITH WIRE CLIP (INLET & EXHAUST) NISSAN/DATSUN L18	NISSAN/DATSUN	L18	85.00	OEM # (IN. & EX.) 1321221011, 1321321011 & 13213U0110	SBI # (IN. & EX.) 140- 7499
V051P04020200N	VALVE GUIDE (INLET & EXHAUST) PETTER AA-1,AB-1,AC-1 (IN. & EX. BOTH ARE SAME.)	PETTER	AA-1,AB- 1,AC-1	69.85,76.20	OEM # 320157	AE # VAG-50967 & TRW # 110-G50967
V051P05010110N	VALVE GUIDE (INLET & EXHAUST) PEUGEOT 306 OR SAXO ESS (BRONZE) 1 SET OF 8 NOS. (IN. & EX. BOTH ARE SAME.)	PEUGEOT	306 OR SAXO ESS			IN. & EX. GIEFFE # G52314
V051P05010210N	VALVE GUIDE (INLET & EXHAUST) PEUGEOT 306 OR SAXO ESS (CAST IRON) 1 SET OF 8 NOS. (IN. & EX. BOTH ARE SAME.)	PEUGEOT	306 OR SAXO ESS			IN. & EX. GIEFFE # G52314
V051P05060200N	VALVE GUIDE (INLET & EXHAUST) PEUGEOT 404 (IN. & EX. BOTH ARE SAME.) STD (O.D.-14.08MM)	PEUGEOT	404	84.00,85.00	OEM # 022025	
V051P05070110N	VALVE GUIDE (INLET & EXHAUST) PEUGEOT 405 (BRONZE) 1 SET OF 8 NOS.	PEUGEOT	405	83.00		IN. GIEFFE # G52434 & EX. GIEFFE # G52053
V051P05340110N	VALVE GUIDE (INLET & EXHAUST) PEUGEOT 406D (BRONZE) 1 SET OF 8 NOS.	PEUGEOT	406D			IN. & EX. GIEFFE # G52290
V051P05080210N	VALVE GUIDE (INLET & EXHAUST) PEUGEOT 504 (CAST IRON) 1 SET OF 8 NOS. (IN. & EX. BOTH ARE SAME.)	PEUGEOT	504	84.00/88.00/ 90.00		IN. & EX. GIEFFE # G50942



V051P05330110N	VALVE GUIDE (INLET & EXHAUST) PEUGEOT BOXER (BRONZE) 1 SET OF 8 NOS. (IN. & EX. BOTH ARE SAME.)	PEUGEOT	BOXER		OEM # 022093	IN. & EX. GIEFFE # G52529 & FRECCIA # G3566
V051R03330110N	VALVE GUIDE (INLET & EXHAUST) RENAULT - CLIO (BRONZE) 1 SET OF 8 NOS.	RENAULT	CLIO D/19D/21D /MAGANE D/EXPRESS 1.9D			IN. GIEFFE #=G52502 & EX. GIEFFE #=#G52510
V051R03270110N	VALVE GUIDE (INLET & EXHAUST) RENAULT - MAGANE SCENIC (BRONZE) 1 SET OF 8 NOS.	RENAULT	MEGANE SCENIC			IN. GIEFFE #=G52582 & EX. GIEFFE #=#G52682
V051R03350110N	VALVE GUIDE (INLET & EXHAUST) RENAULT 1.9D (BRONZE) 1 SET OF 8 NOS. (IN. & EX. BOTH ARE SAME.)	RENAULT	1.9D			IN. & EX. GIEFFE # G52105 & FRECCIA # 3244
V051R03080111N	VALVE GUIDE (INLET & EXHAUST) RENAULT MAGANE 1.9 DTI (BRONZE) 1 SET OF 8 NOS. (IN. & EX. BOTH ARE SAME.) VALVE GUIDE TL.-38.30MM	RENAULT	MEGANE 1.9D			IN. & EX. GIEFFE # G52585
V051R03080110N	VALVE GUIDE (INLET & EXHAUST) RENAULT MAGANE 1.9 DTI (BRONZE) 1 SET OF 8 NOS. (IN. & EX. BOTH ARE SAME.) VALVE GUIDE TL.-49.00MM	RENAULT	MEGANE 1.9D			IN. & EX. GIEFFE # G52585
V051R03200100N	VALVE GUIDE (INLET & EXHAUST) RENAULT R18/20/25, TRAFIC MASTER (DIESEL) IN. & EX. BOTH ARE SAME. (BRONZE)	RENAULT	R18/20/25, TRAFIC MASTER (DIESEL)			METELLI #=#01-2054
V051R03220200N	VALVE GUIDE (INLET & EXHAUST) RENAULT R19 (CAST IRON) IN. & EX. BOTH ARE SAME.	RENAULT	R19			GIEFFE #=#G52502 & G52510
V051R03130210N	VALVE GUIDE (INLET & EXHAUST) RENAULT R4/5/6/7/8 (CAST IRON) 1 SET OF 8 NOS. (IN. & EX. BOTH ARE SAME.)	RENAULT	R4/5/6/7/8		OEM # 0710939000	TRW # 81-5115
V051R03130200N	VALVE GUIDE (INLET & EXHAUST) RENAULT R4/5/6/7/8 (IN. & EX. BOTH ARE SAME.)	RENAULT	R4/5/6/7/8		OEM # 0710939000	TRW # 81-5115
V051R03290100N	VALVE GUIDE (INLET & EXHAUST) RENAULT R9/11 (DIESEL) IN. & EX. BOTH ARE SAME. (BRONZE)	RENAULT	R9/11 (DIESEL)			METELLI #=#01-2105 & H.M. ALGERIA PART NO.-52105
V051R06020200N	VALVE GUIDE (INLET & EXHAUST) ROBSON RC (22 HP) IN. & EX. BOTH ARE SAME.	ROBSON	RC (22 HP)			
V051R10020200N	VALVE GUIDE (INLET & EXHAUST) RUMANIA D-15/17 (IN. & EX. BOTH ARE SAME.)	RUMANIA	D-15/17	140.00		
V051R10040200N	VALVE GUIDE (INLET & EXHAUST) RUMANIA UTB-500,UTB-650	RUMANIA	UTB- 500,UTB- 650	108.00		
V051R11020200N	VALVE GUIDE (INLET & EXHAUST) RUSSIA DT-75	RUSSIA	DT-75	120.00		
V051R12020200N	VALVE GUIDE (INLET & EXHAUST) RUSSIAN T-62 (IN. & EX. BOTH ARE SAME.)	RUSSIAN	T-62			
V051R13020200N	VALVE GUIDE (INLET & EXHAUST) RUSSIAN BELARUS MTZ-50,MTZ-80 (IN. & EX. BOTH ARE SAME.)	RUSSIAN BELARUS	MTZ- 50,MTZ-80	110.00		

# AECO ENGINEERING CO.



V051R14500200N	VALVE GUIDE (INLET & EXHAUST) RUSTON YDA (IN. & EX. BOTH ARE SAME.)	RUSTON	YDA	111.176		
V051R14520200N	VALVE GUIDE (INLET & EXHAUST) RUSTON YE (IN. & EX. BOTH ARE SAME.)	RUSTON	YE	127.00		
V051R14530200N	VALVE GUIDE (INLET & EXHAUST) RUSTON YWA (IN. & EX. BOTH ARE SAME.)	RUSTON	YWA	101.60		
V051S02010200Y	VALVE GUIDE (INLET & EXHAUST) SAME - ENG. 1054P (TURBO) BUFFALO/MINITAURO/PANTER	SAME	ENG. 1054P (TURBO) BUFFALO/ MINITAURO /PANTER	105.00	OEM # (IN.) 06214160 & (EX.) 06214170	METELLI # (IN.) 01- 1929 & (EX.) 01- 1930
V051S06060200N	VALVE GUIDE (INLET & EXHAUST) SCANIA 113,DS11,DSC11,DS14,DSC14	SCANIA	113,DS11,D SC11,DS14, DSC14	127.00	OEM # (IN.) 300957 & (EX.) 300958	AE # (IN.) VAG92166, (EX.) VAG92167; TRW # (IN.) 110-G51117, (EX.) 110-G51118 & DT # (IN.) 1.10230SP
V051S06110332N	VALVE GUIDE (INLET & EXHAUST) SCANIA 113,DS11,DSC11,DS14,DSC14 (1 SET OF 12 NOS.)	SCANIA	113,DS11,D SC11,DS14, DSC14	127.00	OEM # (IN.) 300957 & (EX.) 300958	AE # (IN.) VAG92166, (EX.) VAG92167; TRW # (IN.) 110-G51117, (EX.) 110-G51118 & DT # (IN.) 1.10230SP
V051S07030200N	VALVE GUIDE (INLET & EXHAUST) SENDLING DM-15 (IN. & EX. BOTH ARE SAME.)	SENDLING	DM-15			
V051S08030200N	VALVE GUIDE (INLET & EXHAUST) SHIBAURA GD-65/GD-75/GD-85 (IN. & EX. BOTH ARE SAME.)	SHIBAURA	GD-65/GD- 75/GD-85			
V051S12020200N	VALVE GUIDE (INLET & EXHAUST) SLAVIA D-15 (IN. & EX. BOTH ARE SAME.)	SLAVIA	D-15	155.00		
V051S12030200N	VALVE GUIDE (INLET & EXHAUST) SLAVIA D-5 (IN. & EX. BOTH ARE SAME.)	SLAVIA	D-5	100.00		
V051S12070200N	VALVE GUIDE (INLET & EXHAUST) SLAVIA IS 100K (IN. & EX. BOTH ARE SAME.)	SLAVIA	IS 100K			
V051S14030200N	VALVE GUIDE (INLET & EXHAUST) STEYR WD 408 (768)	STEYR	WD 408 (768)			
V051S17020200N	VALVE GUIDE (INLET & EXHAUST) SUBARU EJ18, EJ22, EJ22T (4 CYL.) IN. & EX. BOTH ARE SAME.	SUBARU	EJ18, EJ22, EJ22T			SBI #=-140-8203
V051S18060200N	VALVE GUIDE (INLET & EXHAUST) SUZUKI F10A, G10 (IN. & EX. BOTH ARE SAME.)	SUZUKI	F10A, G10			
V051S18090212N	VALVE GUIDE (INLET & EXHAUST) SUZUKI G10, G13A, G13B & G16A (4 CYL.) IN. W/O POCKET & EX. WITH POCKET (AB)	SUZUKI	G10, G13A, G13B & G16A		OEM # 1111582000	METALLI # 01-2611
V051S18090213N	VALVE GUIDE (INLET & EXHAUST) SUZUKI G10, G13A, G13B & G16A (8 VALVES) 4 CYL. (IN. & EX. BOTH ARE SAME.) NP	SUZUKI	G10, G13A, G13B & G16A (8 VALVES)		OEM # 111158200000 1 & 111158650000 1	SBI # 140-8016

# AECO ENGINEERING CO.



V051S18110200N	VALVE GUIDE (INLET & EXHAUST) SUZUKI G13BA (4 CYL.) IN. & EX. BOTH ARE SAME.	SUZUKI	G13BA			
V051S18120200N	VALVE GUIDE (INLET & EXHAUST) SUZUKI G16B, J20A (4 CYL.) IN. & EX. BOTH ARE SAME.	SUZUKI	G16B, J20A		OEM #=11115-60B11	METALLI #=01-S2635
V051S18220200N	VALVE GUIDE (INLET & EXHAUST) SUZUKI ST-90	SUZUKI	ST-90		OEM#=IN.=11115-73030 & EX.=11116-73030	
V051T06010200N	VALVE GUIDE (INLET & EXHAUST) TOYOTA 12R (INLET W/O POCKET & EXHAUST WITH POCKET)	TOYOTA	12R	80.50	OEM # (IN.) & (EX.) 111223010 & 111223011	AE # VAG92136, TRW # G1201 & SBI # 140-8170
V051T06030200N	VALVE GUIDE (INLET & EXHAUST) TOYOTA 18R	TOYOTA	18R	88.50	OEM # (IN.) 1112233011 & (EX.) 1112633011	TRW # (IN.) G1024 & (EX.) G1026
V051T06050200N	VALVE GUIDE (INLET & EXHAUST) TOYOTA 1FZFE (IN. & EX. BOTH ARE SAME.)	TOYOTA	1FZFE			
V051T06710200N	VALVE GUIDE (INLET & EXHAUST) TOYOTA 1HZ (IN. & EX. BOTH ARE SAME.)	TOYOTA	1HZ	94.00	OEM # 1112254020	
V051T06190210N	VALVE GUIDE (INLET & EXHAUST) TOYOTA 2B,3B,14B (1 SET OF 8 NOS.) IN. & EX. BOTH ARE SAME. (FULLY BLACK FINISH EXCEPT I.D.)	TOYOTA	2B,3B,14B	98.00,102.00	OEM # 1112256030	METELLI # 01-2455
V051T06190231N	VALVE GUIDE (INLET & EXHAUST) TOYOTA 2B,3B,14B (IN. & EX. BOTH ARE SAME.) FULLY BLACK FINISH EXCEPT I.D.	TOYOTA	2B,3B,14B	98.00,102.00	OEM # 1112256030	METELLI # 01-2455
V051T06800232N	VALVE GUIDE (INLET & EXHAUST) TOYOTA 2E (1 SET OF 12 NOS.) IN. & EX. BOTH ARE SAME	TOYOTA	2E	73.00	OEM # 1112210040	METELLI # 01-2206
V051T06220200N	VALVE GUIDE (INLET & EXHAUST) TOYOTA 2F,3F	TOYOTA	2F,3F	94.00	OEM # (IN.) 1112261011 & (EX.) 1112661011	
V051T06250200N	VALVE GUIDE (INLET & EXHAUST) TOYOTA 2H,12HT,2J (IN. & EX. BOTH ARE SAME.)	TOYOTA	2H,12HT,2J	88.00,91.00	OEM # 1112246010	ACL # VG859 & NATIONAL PART # VG601
V051T06850210N	VALVE GUIDE (INLET & EXHAUST) TOYOTA 2KD (1 SET OF 8 NOS.) IN. & EX. BOTH ARE SAME	TOYOTA	2KD	73.00	OEM # 1112210040	METELLI # 01-2206
V051T06610200N	VALVE GUIDE (INLET & EXHAUST) TOYOTA 2R,12R (2 COTTERS GROOVE)	TOYOTA	2R,12R	78.00,80.50	OEM # (IN.) 1112231012 & (EX.)	PART # (IN.) VG2000 & (EX.) VG2001 (VG757)
V051T06340200N	VALVE GUIDE (INLET & EXHAUST) TOYOTA 3E,3FE (IN. & EX. BOTH ARE SAME.)	TOYOTA	3E,3FE	73.00	OEM # 1112210040	METELLI # 01-2206 & SBI # 140-8195
V051T06820210N	VALVE GUIDE (INLET & EXHAUST) TOYOTA 3L,5L (IN. & EX. BOTH ARE SAME.) 1 SET OF 8 NOS.	TOYOTA	3L,5L	99.50	OEM # 1112268010	METELLI # 01-2493
V051T06640210N	VALVE GUIDE (INLET & EXHAUST) TOYOTA 4AFE,7AFE (IN. & EX. BOTH ARE SAME.) 1 SET OF 8 NOS.	TOYOTA	4AFE,7AFE	81.00	OEM # 1112215030 & 1112274030	METELLI # 01-2697 & SBI # 140-8147

# AECO ENGINEERING CO.



V051T06440200N	VALVE GUIDE (INLET & EXHAUST) TOYOTA 5R (INLET W/O POCKET & EXHAUST WITH POCKET)	TOYOTA	5R	88.00	OEM # (IN.) & (EX.) 1112244010	AE # VAG92154
V051T06520212N	VALVE GUIDE (INLET & EXHAUST) TOYOTA B,2B,3B (INLET W/O POCKET & EXHAUST WITH POCKET) AB	TOYOTA	B,2B,3B	95.00,98.00,1 02.00	OEM # (IN.) & (EX.) 1112256020	NP & VN PART # VG2020, NVG PART # NVG0604 & TRW # G1191
V051T06580200N	VALVE GUIDE (INLET & EXHAUST) TOYOTA L,2L (INLET W/O POCKET & EXHAUST WITH POCKET)	TOYOTA	L,2L	90.00,92.00	OEM # (IN.) & (EX.) 1112254011	AE # VAG92282 & TRW # G2001
V071T06100210N	VALVE GUIDE WITH WIRE CLIP (INLET & EXHAUST) TOYOTA 1Y,2Y,3Y (C.I.) STD (1 SET OF 8 NOS.)	TOYOTA	1Y,2Y,3Y	86.00	OEM # (IN.) 1112271020 & (EX.) 1112671020, 1112640010	METELLI # (IN.) 01- 2360 & (EX.)
V051U01010200N	VALVE GUIDE (INLET & EXHAUST) URSUS TRACTOR C-330 (IN. & EX. BOTH ARE SAME.)	URSUS TRACTOR	C-330	102.00	OEM # 50001020	
V051U01030200N	VALVE GUIDE (INLET & EXHAUST) URSUS TRACTOR C-355/C-355M,C-360	URSUS TRACTOR	C-355/C- 355M,C-360	95.00	OEM # (IN.) 50505040 & (EX.) 50505300	
V051V06130110N	VALVE GUIDE (INLET & EXHAUST) VOLKSWAGEN GOLF 1.9 TDI (BRONZE) 1 SET OF 8 NOS. (IN. & EX. BOTH ARE SAME.)	VOLKSWAG EN	GOLF 1.9 TDI			IN. & EX. GIEFFE # G52470 & SM # 88- 0222
V051V06140110N	VALVE GUIDE (INLET & EXHAUST) VOLKSWAGEN GOLF GTD (BRONZE) 1 SET OF 8 NOS. (IN. & EX. BOTH ARE SAME.)	VOLKSWAG EN	GOLF GTD		OEM # 419652	IN. & EX. GIEFFE # G51227 & FRECCIA # G2644
V051V07040200N	VALVE GUIDE (INLET & EXHAUST) VOLVO D42 OR BOLINDER 650 (IN. & EX. BOTH ARE SAME.)	VOLVO	D42	105.57	OEM # 785597	
V051V07190200N	VALVE GUIDE (INLET & EXHAUST) VOLVO D60,TD60,TD60A,TD60B,TD60C,TD61F (IN. & EX. BOTH ARE SAME.)	VOLVO	D60,TD60,T D60A,TD60 B,TD60C,TD 61F	98.425	OEM # 465157- 6	METALLI # 01-1912, AE # VAG-92096, TRW # 81-4720, FRECCIA # G3506 & BF # 20080406001
V051V07100200N	VALVE GUIDE (INLET & EXHAUST) VOLVO D70A,D70B,D70C,TD70A,TD70B,TD70C, TD70E,TD70F,TD70G,TD70H (IN. & EX. BOTH ARE SAME.)	VOLVO	D70A,D70B, D70C,TD70 A,TD70B,TD 70C,TD70E, TD70F,TD7 0G,TD70H	104.775	OEM # 421297, 421297-3 & 466386	AE # VAG-92080 & TRW # 110-G50932, 110-G51119 & BF # 20080406001
YAMAHA0007	VALVE GUIDE (INLET & EXHAUST) YAMAHA YBX-4S,YD-125cc,ENTICER	YAMAHA	YBX-4S,YD- 125cc,ENTI CER	54.00		
V051Y02130200N	VALVE GUIDE (INLET & EXHAUST) YANMAR 2T,3T (IN. & EX. BOTH ARE SAME.)	YANMAR	2T,3T	95.00		
V051Y02160200N	VALVE GUIDE (INLET & EXHAUST) YANMAR 3EKD/4EKD	YANMAR	3EKD/4EKD	130.00	OEM # (IN.) 12641011160 & (EX.) 12641011170	
V051Y02080200N	VALVE GUIDE (INLET & EXHAUST) YANMAR 3ES/4ES	YANMAR	3ES	115.00		

# AECO ENGINEERING CO.



V051Y02340200N	VALVE GUIDE (INLET & EXHAUST) YANMAR KD/4KD	YANMAR	KD	145.00	OEM # (IN.) 13560211162 & (EX.) 13521011172	
V051Y02390200N	VALVE GUIDE (INLET & EXHAUST) YANMAR N22Y	YANMAR	N22Y	140.00	OEM # (IN.) 10320011170 & (EX.) 10320211180	
V051Y02420200N	VALVE GUIDE (INLET & EXHAUST) YANMAR NP-16 (IN. & EX. BOTH ARE SAME.)	YANMAR	NP-16	110.00		
V051Y02380200N	VALVE GUIDE (INLET & EXHAUST) YANMAR NT-110,N15Y (IN. & EX. BOTH ARE SAME.)	YANMAR	NT- 110,N15Y	110.00	OEM # 10310011160	
V051Y02460200N	VALVE GUIDE (INLET & EXHAUST) YANMAR NT-65 (IN. & EX. BOTH ARE SAME.)	YANMAR	NT-65	65.00		
V051Y02470200N	VALVE GUIDE (INLET & EXHAUST) YANMAR NT-70 (IN. & EX. BOTH ARE SAME.)	YANMAR	NT-70	70.00		
V051Y02480200N	VALVE GUIDE (INLET & EXHAUST) YANMAR NT-75 (IN. & EX. BOTH ARE SAME.)	YANMAR	NT-75	75.00		
V051Y02500207N	VALVE GUIDE (INLET & EXHAUST) YANMAR NT-85 (IN. & EX. BOTH ARE SAME.) KSKCL	YANMAR	NT-85	85.00		
V051Y02500208N	VALVE GUIDE (INLET & EXHAUST) YANMAR NT-85 (IN. & EX. BOTH ARE SAME.) OLD	YANMAR	NT-85	85.00		
V051Y02510200N	VALVE GUIDE (INLET & EXHAUST) YANMAR NT-95 (IN. & EX. BOTH ARE SAME.)	YANMAR	NT-95	95.00		
V051Y02570200N	VALVE GUIDE (INLET & EXHAUST) YANMAR SM3/SM4	YANMAR	SM3/SM4	105.00		
V051Y02620200N	VALVE GUIDE (INLET & EXHAUST) YANMAR TA-80/SA-80 (IN. & EX. BOTH ARE SAME.) KSKCL	YANMAR	TA-80/SA- 80	84.00		
V051Y02620209N	VALVE GUIDE (INLET & EXHAUST) YANMAR TA-80/SA-80 (IN. & EX. BOTH ARE SAME.) SMVLP	YANMAR	TA-80/SA- 80	84.00		
V051Y02670200N	VALVE GUIDE (INLET & EXHAUST) YANMAR TF-105/TF-110,TF-115/TF- 120 (IN. & EX. BOTH ARE SAME.) KSKCL	YANMAR	TF-105/TF- 110,TF- 115/TF-120	88.00,92.00	OEM # 10550011800	
V051Y02670209N	VALVE GUIDE (INLET & EXHAUST) YANMAR TF-105/TF-110,TF-115/TF- 120 (IN. & EX. BOTH ARE SAME.) SMVLP	YANMAR	TF-105/TF- 110,TF- 115/TF-120	88.00,92.00	OEM # 10550011800	
V051Y02330200N	VALVE GUIDE (INLET & EXHAUST) YANMAR TF-75/TF-80,TF-85/TF-90 (IN. & EX. BOTH ARE SAME.) KSKCL	YANMAR	TF-75/TF- 80,TF- 85/TF-90	80.00,85.00	OEM # 10530011800 & 10530011801	
V051Y02740209N	VALVE GUIDE (INLET & EXHAUST) YANMAR TF-75/TF-80,TF-85/TF-90 (IN. & EX. BOTH ARE SAME.) SMVLP	YANMAR	TF-75/TF- 80,TF- 85/TF-90	80.00,85.00	OEM # 10530011800 & 10530011801	
V051Y02800207N	VALVE GUIDE (INLET & EXHAUST) YANMAR TH-10/TS-155 (IN. & EX. BOTH ARE SAME.) KSKCL	YANMAR	TH-10/TS- 155	95.00	OEM # 10385411160	

V051Y02800208N	VALVE GUIDE (INLET & EXHAUST) YANMAR TH-10/TS-155 (IN. & EX. BOTH ARE SAME.) OLD	YANMAR	TH-10/TS-155	95.00	OEM # 10385411160	
V051Y02840207N	VALVE GUIDE (INLET & EXHAUST) YANMAR TH-3/TS-50 (IN. & EX. BOTH ARE SAME.) KSKCL	YANMAR	TH-3/TS-50	70.00		
V051Y02840208N	VALVE GUIDE (INLET & EXHAUST) YANMAR TH-3/TS-50 (IN. & EX. BOTH ARE SAME.) OLD	YANMAR	TH-3/TS-50	70.00		
V051Y02850207N	VALVE GUIDE (INLET & EXHAUST) YANMAR TH-4/TS-60 (IN. & EX. BOTH ARE SAME.) KSKCL	YANMAR	TH-4/TS-60	75.00		
V051Y02850208N	VALVE GUIDE (INLET & EXHAUST) YANMAR TH-4/TS-60 (IN. & EX. BOTH ARE SAME.) OLD	YANMAR	TH-4/TS-60	75.00		
V051Y02860207N	VALVE GUIDE (INLET & EXHAUST) YANMAR TH-5/TS-70,TH-6/TS-80 (IN. & EX. BOTH ARE SAME.) KSKCL	YANMAR	TH-5/TS-70,TH-6/TS-80	80.00	OEM # 10630011160	
V051Y02860209N	VALVE GUIDE (INLET & EXHAUST) YANMAR TH-5/TS-70,TH-6/TS-80 (IN. & EX. BOTH ARE SAME.) SMVLP	YANMAR	TH-5/TS-70,TH-6/TS-80	80.00	OEM # 10630011160	
V051Y02770207N	VALVE GUIDE (INLET & EXHAUST) YANMAR TH-7/TS-105,TH-8/TS-130 (IN. & EX. BOTH ARE SAME.) KSKCL	YANMAR	TH-7/TS-105,TH-8/TS-130	85.00/92.00	OEM # 10558211160	
V051Y02770209N	VALVE GUIDE (INLET & EXHAUST) YANMAR TH-7/TS-105,TH-8/TS-130 (IN. & EX. BOTH ARE SAME.) SMVLP	YANMAR	TH-7/TS-105,TH-8/TS-130	85.00,92.00	OEM # 10558211160	
V051Z01020200N	VALVE GUIDE (INLET & EXHAUST) ZETOR 102 (IN. & EX. BOTH ARE SAME.)	ZETOR	102	102.00		
V051Z01030200N	VALVE GUIDE (INLET & EXHAUST) ZETOR 105 (ZETOR 50,HINDUSTAN 50,SUPER 25) IN. & EX. BOTH ARE SAME.	ZETOR	105	105.00	OEM # 105040	
V051Z01040200N	VALVE GUIDE (INLET & EXHAUST) ZETOR 110 (IN. & EX. BOTH ARE SAME.)	ZETOR	110	110.00		
V051Z01090200N	VALVE GUIDE (INLET & EXHAUST) ZETOR 95 (2001/2011/3001/3011/4001)	ZETOR	95 (2001/2011/3001/3011/4001)	95.00	OEM # (IN.) 950504, 50505040 & (EX.) 950530, 50505300	TRW # (IN.) 81-4204 & (EX.) 81-4205, FRECCIA # (IN.) G2676 & (EX.) G2677, METELLI # (IN.) 01-1027 &
V051Z01120200N	VALVE GUIDE (INLET & EXHAUST) ZETOR Z7201 (IN. & EX. BOTH ARE SAME.)	ZETOR	Z7201	102.00	OEM # 69010567	
V051Z01130200N	VALVE GUIDE (INLET & EXHAUST) ZETOR Z8001,Z8002.1 (IN. & EX. BOTH ARE SAME.)	ZETOR	Z8001,Z8002.1	110.00	OEM # 80005101	FRECCIA # G3073 & METELLI # 01-2210
V051Z01140200N	VALVE GUIDE (INLET & EXHAUST) ZETOR Z8001,Z8002.1 (TURBO) OR URSUS TRACTOR C-385	ZETOR	Z8001,Z8002.1 (TURBO)	110.00	OEM # (IN.) 89005508 & (EX.) 89005518	